

NOTE

MOUNT CHASSIS SECTION OF SLIDES
TO CHASSIS USING CHASSIS TRAK
HARDWARE —

XDF-50/20/70/76/90
SLIDE KIT MOUNTING DETAIL

100602

XDF-50
DRIVER FLOW CHART EXPLANATION

1) The following parameters are provided by the calling program:

- a) Unit (0-3)
- b) Pack (0-1)
- c) Cylinder (0-C) C = Last Cylinder #
- d) Track (0-1)
- e) Sector (0-S) S = (# Sectors/Revolution) - 1
- f) Type of Operation
- g) Memory Address
- h) Word Count

2) The driver transfers a maximum of one sector per call. The memory address and word count should be set according to the type of operation as follows:



- a) For the following operations the memory address should point to the first word of data to be transferred and the word count should be less than or equal to the number of data words per sector.

<u>Operation Code</u>	<u>Operation</u>
2	Normal Write Operation
3	Normal Read Operation
5	Normal Write Ignoring the Sector Write Protect Flag
7	Read Without Checking the Preamble


- b) For the following operation the memory address should point two words prior to the data to be transferred (if any) and the word count should be greater than or equal to 2 and less than or equal to the number of data words per sector plus 2. The words preceeding the data should contain a properly formatted preamble for the sector to be written.

<u>Operation Code</u>	<u>Operation</u>
1	Write Preamble and Data


3) The entry point to the driver is DSIO. BGSK is an internal subroutine used to select the unit and initiate seeks. A normal exit from DSIO indicates that the operation was completed without error. An error exit from either DSIO or BGSK returns an error code that indicates the error that was detected. In either case the term "exit" refers to a return to the program that called DSIO.



XDF-50 BASIC I/O DRIVER
FLOW CHART



NOVA
1220-820, SERIES



NOVA
800-1200-NOVA
SERIES

5	2	199325	SCREW-4-40X 3/8 STUDER HD.
4	1	100541	PLATE- CONDUCTOR MOUNT
3	2	100534	BRACKET-CONNECTOR MOUNT
2	1	194114	CANNON-SCREWLOCK HARDWARE
1	1		NOVA-INTERNAL CABLE ASSEMBLY
ITEM	QTY	XPN	DESCRIPTION

XEBEC SYSTEMS INC

100676
15-AUL-713

NOVA

INTERNAL CABLE MOUNTING DETAILS


MATERIAL
AS NOTED

XPN

100676

REV
B

REV
A



NOTE

MOUNT CHASSIS SECTION OF SLIDES TO CHASSIS USING CHASSIS TRAK HARDWARE —



XDF-50

SLIDE KIT MOUNTING DETAIL

100602



INSTALLATION DIAGRAM

NOVA SERIES/XDF-50/CMD DISK



INTERNAL HARNESS
BY XEBEC

NOTE - USE XEBEC SUPPLIED DETAIL
INSTALLATION INSTRUCTIONS



INTERNAL
HARNESS

